

Product Description

Versa Quartz is a premium quartz tile that provides the durability and ease of maintenance the commercial flooring market demands. Versa Quartz combines a unique and creative esthetic with unmatched performance and incredible durability to provide a solution for any commercial environment.

Versa Quartz is manufactured in the USA using a combination of vinyl, natural raw materials, and synthetic polymers to produce one of the most durable commercial floor tiles in the industry. Versa Quartz is manufactured from 70% quartz, a naturally abundant and durable raw material, which allows it to meet or exceed most demands in the commercial flooring market.

Ideal For:

- **Education:** Classrooms, hallways and multi-purpose rooms
- **Healthcare:** exam rooms, corridors and equipment or exam rooms
- **Assisted Living:** Hallways, rooms and eating or congregation areas.
- **Retail Spaces:** showrooms, shopping malls and retail stores.

Features

- **Manufactured from Natural Raw Materials**
- **Easy To Maintain**
- **Superior Indentation Resistance**
- **Superior Durability**
- **Excellent Chemical Resistance**
- **Excellent Slip Resistance**
- **Qualifies for LEED® Credits**
- **FloorScore® Certified**

Technical Data

Dimensions: **12" x 12" x 2.5 mm**
12" x 24" x 2.5 mm
24" x 24" x 2.5 mm

Finish: **Smooth**

Weight Per Tile: **1 lbs. (12" x 12")**
2 lbs. (12" x 24")
4 lbs. (24" x 24")

Quantity Per Carton: **55 Tiles (12" x 12")**
20 tiles (12" x 24")
10 tiles (24" x 24")

LEED v2009 IEQ Credit 4.1: **Qualifies**

LEED v2009 IEQ Credit 4.3: **Qualifies**

ASTM F1066 - Vinyl Composition Tile: **Meets or Exceeds Requirements**

ASTM F1700 - Solid Vinyl Tile: **Passes, Unclassified**

ASTM E648 - Critical Radiant Flux: **> 1.08 W/ cm², Class I**

ASTM E662 - Smoke Density: **Passes, < 450**

ASTM E2240 - Hardness: **> 65, Shore D**

ASTM D2047 - Slip Resistance: **> 0.5**

ASTM F970 - Static Load Limit: **Passes, 250 PSI**

ASTM F970 (Modified)- Max Weight: **3500 PSI**

ASTM F925 - Chemical Resistance: **Excellent** (*chart available*)

ASTM D3389 - Abrasion Resistance: **Excellent**

Acclimation Time: **48 Hours**

Storage & Acclimation Temperature: **65° - 85° F**

Additional Information

Approved Adhesives

SP-500 Acrylic Aerosol
AP-520 Acrylic Roll-On
AW-510 Acrylic Wet-Set Adhesive
EW-710 Epoxy Wet-Set Adhesive

Availability, Cost & Samples

Procedo Flooring products are sold through appointed sales representatives. To locate the nearest representative, contact Procedo Customer Service at (866) - 955 - 8291 or send an e-mail to support@procedoflooring.com

Technical Documents & Support

Additional product resources and technical documents are available online at procedoflooring.com or through the nearest sales representative. For additional technical support, send an email to solutions@rhctechical.com.

1. PRE-INSTALLATION CHECKLIST

- Consult all associated product literature concerning adhesive installation, maintenance and warranty prior to installation of flooring.
- Allow all trades to complete work prior to installation.
- Deliver all materials to the installation location in its original packaging with labels intact.
- Do not stack pallets to avoid damage.
- Remove any plastic and strapping from product after delivery.
- Remove material from packaging and stack evenly on a smooth, dry surface. Do not stack higher than 18”.
- Inspect all material for proper type, color and matching lot numbers or production codes if appropriate.
- Ensure that all adhesives intended for installation are approved for use with flooring material.
- Ensure installation area and material storage temperatures are between 65° F (19° C) and 85° F (30° C) for at least 48 hours before, during and after installation.
- Ensure HVAC system is operational and fully functioning at normal operating conditions.
- Protect installation area from extreme temperature changes, such as heat and freezing, as well as direct sunlight for at least 48 hours before, during and after installation.
- Ensure all substrate preparation and moisture testing requirements have been read and understood by all interested parties.
- Test substrate for porosity in order to determine the installation method necessary.
- Ensure all vents, walls, moldings and/or doorways are protected with tape or plastic prior to installation.
- Do not proceed with installation until all conditions have been met.

2. PRODUCT LIMITATIONS

Do not install materials over LVT, cushioned vinyl, hardwood flooring, cork, rubber, or asphaltic materials. Do not install flooring materials in outdoor areas, in or around commercial kitchens or areas that may be exposed to oil, grease and other petroleum-based hydrocarbons. Do not install in areas that may be subjected to sharp, pointed objects, such as stiletto heels, cleats or spikes. Do not allow product to be directly exposed to extreme heat sources, such as radiators, ovens or other high-heat equipment. May be susceptible to staining from rubber tires, casters or rubber-backed walk-off mats, as well as harsh disinfectants, cleaning agents, dyes or other harsh chemicals – ensure all chemicals and materials that may come in contact with flooring surface will not stain, mar or otherwise damage the flooring material prior to use. This product is manufactured to be commercial product and is not manufactured or meet any residential requirements for use

3. SUBSTRATE PREPARATION

All substrates must be prepared according to ASTM F710, as well as applicable ACI and RFCI guidelines. Substrates must be clean, smooth, permanently dry, flat, and structurally sound. Substrates must be free of visible water or moisture, dust, sealers, paint, sweeping compounds, curing compounds, residual adhesives and adhesive removers, concrete hardeners or densifiers, solvents, wax, oil, grease, asphalt, visible alkaline salts or excessive efflorescence, mold, mildew and any other extraneous coating, film, material or foreign matter.

All substrates must have any and all existing adhesives, materials, contaminants or bond-breakers mechanically removed via scraping, sanding, grinding or buffing with a 25 grit DiamaBrush Prep Plus tool prior to adhesive installation. In extreme situations, shotblasting may be required. Mechanical preparation must expose

at least 90% of the original substrate. Following cleaning and removal, all substrates must be vacuumed with a flat vacuum attachment or damp mopped with clean, potable water to remove all surface dust. Sweeping without vacuuming or damp mopping will not be acceptable.

All porous substrates must be tested per ASTM F3191 to confirm porosity. Use a pipette or equivalent to conduct three tests by placing a .05 mL (1/4” wide) droplet of clean, potable water onto the surface. If the substrate absorbs water within 60 seconds, the substrate is considered porous. Conduct 3 tests for the first 3000 sq. ft. and one for each additional 2000 sq. ft., at least one per room. All other substrates that do not meet this requirement are considered non-porous. Ensure that all non-porous substrates are not contaminated with any aforementioned contaminants.

It is recommended that all substrates have a floor flatness of FF32 and/or a flatness tolerance of 1/8” in 6’ or 3/16” in 10’. Substrates that do not meet this requirement should have a compatible cementitious patch (such as the Excelsior CP-300) or self-leveling underlayment (such as the Excelsior SU-310) installed to flatten the installation area.

Do not use solvent/citrus based adhesive removers prior to installation. Follow The Resilient Floor Covering Institute’s (RFCI) “Recommended Work Practice for Removal of Existing Floor Covering and Adhesive”, and all applicable local, state, federal and industry regulations and guidelines. When removing asbestos and asbestos containing materials, follow all applicable OSHA standards.

CONCRETE SUBSTRATES

All concrete must have a minimum compressive strength of 3500 PSI and be prepared in accordance with ASTM F710. When flooring is being installed directly over concrete, concrete surfaces that have an ICRI Concrete Surface Profile (CSP) over 4 should be smoothed with a self-leveling underlayment

(such as the Excelsior SU-310) or a cementitious patch (such as the Excelsior CP-300) to prevent imperfections from telegraphing through flooring materials.

Adhesive RH Limits

- SP-500 Acrylic Aerosol: **90% RH**
- AP-520 Acrylic Roll-On: **80% RH**
- AW-510 Acrylic Wet Set: **90% RH**
- EW-710 Epoxy Wet-Set: **90% RH**

On or below grade concrete must have a permanent, effective moisture vapor retarder installed below the slab.

New or existing concrete substrates on all grade levels must be tested in accordance with ASTM F2170, using in

Adhesive MVER Limits

- SP-500 Acrylic Aerosol: **10 lbs.**
- AP-520 Acrylic Roll-On: **6 lbs**
- AW-510 Acrylic Transition: **6 lbs.**
- EW-710 Epoxy Wet-Set: **6 lbs.**

situ Probes (such as Wagner Rapid RH), to quantitatively determine the amount of relative humidity no more than one week prior to the installation.

In addition to ASTM F2170 Relative Humidity Testing, existing concrete that has previously had floor covering installed on all grade levels must be tested in accordance with ASTM F1869, using Calcium Chloride test kits, to quantitatively determine the Moisture Vapor Emissions Rate (MVER) of the concrete.

If ASTM F2170 or ASTM F1869 test results exceed the prescribed limits, a moisture mitigation product, such as Excelsior MM-100 Moisture Mitigation, must be installed prior to proceeding with installation. Do not install flooring until moisture testing has been conducted per the appropriate standard and/or moisture mitigation has been installed and is dry to the touch. Do not install flooring in below grade areas when hydrostatic pressure is visible or suspected.

RESINOUS SUBSTRATES

When installing directly over a resinous

products, such as the Excelsior MM-100 or an epoxy coating, ensure that coating is dry to the touch and has cured for the prescribed length of time. Substrate must be clean, dry, sound and free of contaminates. Ensure to follow installation procedures and trowel sizes for non-porous substrates.

GYPSUM BASED SUBSTRATES

Gypsum-based substrates must have a minimum compressive strength of 3500 PSI. Gypsum substrates that do not meet this requirement must have one coat of the Excelsior MM-100 or equivalent installed to improve the tensile/pull-off strength of the substrate. Substrate must be structurally sound and firmly bonded to subfloor. Any cracked or fractured areas must be removed and repaired with a compatible patch or repair product. Follow instructions for installation over a gypsum substrate. New or existing gypsum substrates may require a sealant or primer. Follow all manufacturer's recommendations regarding preparation for resilient flooring installation.

WOOD SUBSTRATES

Wood substrates must be prepared in accordance with ASTM F1482. Wood subfloors should be of double layer construction with a minimum thickness of 1". Crawl spaces beneath wood subfloors shall be in compliance with local building ventilation codes and have at least 18" of cross-ventilated space between the ground and the joists. Wood joists should be spaced on not more than 16" centers.

Prior to installation, moisture retardant sheeting with a maximum rating of 1.0 perm must be installed beneath the wood subfloor, overlapped at least 8". For standard installations, use Underlayment Grade plywood with a minimum thickness of 1/4" thick and a fully sanded surface. When floors may be subjected to moisture, use an APA approved exterior grade plywood.

Other wood subfloor materials, such as OSB, lauan, particleboard, chipboard, fiberboard or cementitious tile backer boards, are not acceptable subfloors.

Avoid preservative-treated and fire-retardant plywood, as some may be manufactured with resins or adhesives that may cause discoloration or staining of the flooring. Do not install flooring directly over solid or engineered hardwood flooring without first installing plywood or a suitable cementitious repair product at a minimum thickness of 1/4" over the hardwood flooring.

Wood subfloor deflection, movement, or instability will cause the flooring installations to release, buckle or become distorted. As such, do not use plastic or resin filler to patch cracks. Do not use cement or rosin coated nails and staples or solvent-based construction adhesives to adhere the plywood. Do not install on a sleeper system (wood subfloor system over concrete) or directly over Sturd-I-Floor panels.

METAL SUBSTRATES

Metal substrates must be thoroughly sanded/ground and cleaned of any residue, oil, rust and/or oxidation. Substrate must be smooth, flat and sound prior to installation. When installing in areas that may be subject to topical water or moisture and/or high humidity, an anti-corrosive coating must be applied to protect metal substrate. Contact a local paint or coating supplier for coating recommendations. Install flooring material within 12 hours after sanding/grinding to prevent re-oxidation. Any deflection in the metal floor can cause a bond failure between the adhesive and the metal substrate. Ensure to follow installation procedures and trowel sizes for non-porous substrates.

EXISTING FLOORING SUBSTRATES

The suitability of existing flooring as a substrate depends on the specific requirements of the adhesive being used to install the material. As such, refer to the adhesive requirements for existing flooring substrates and ensure all adhesive requirements and guidelines are followed.

RADIANT HEATING SUBSTRATES

When installing flooring over a substrate that contains a radiant heating system,

ensure the radiant heat is turned off 48 hours prior to installation and remains off during the entire installation. 48 hours after installation, the radiant heat may be gradually increased over the course of 24 hours, until normal operating temperature is reached. Ensure the temperature of the radiant heating system does not exceed 85° F (29.5° C) and avoid making abrupt changes in radiant heating temperature.

4. CRACKS, JOINTS & VOIDS

Ensure All cracks, joints and voids, as well as the areas surrounding them, must be clean and free of dust, dirt, debris and contaminants. All minor cracks and voids 3/64" wide or less may be repaired with a suitable cementitious patch.

Due to the dynamic nature of concrete slabs, manufacturer cannot warranty installations to cover expansion joints, cracks or other voids (such as control cuts, saw joints and moving cracks or voids) wider than 3/64". Do not install flooring directly over any expansion joints or cracks wider than 3/64".

All expansion joints should have a suitable expansion joint covering system installed to allow expansion joint to freely move. To treat expansions joints where an expansion joint covering system can't be installed or to treat through cracks (depth at least 75% of the thickness of the concrete), chase joint or crack with a suitable saw or grinder and open to a minimum width of 1/4". Be sure to clean all dust, dirt and debris from crack. Joints and cracks should then be sealed with a suitable, elastomeric caulk (such as Ardex Ardiseal Rapid Plus, Mapei P1 SL or equivalent) designed for use in expansion joints. Install a closed-cell backer rod at prescribed depth and follow caulk manufacturer's instructions for installation. Ensure surface is troweled flush with surface of concrete.

To treat other cracks and voids (such as control cuts, saw-cut joints and surface cracks) over 3/64", chase joint or void with a suitable saw or grinder and clean all dust, dirt and debris

from crack. Fill entire crack with a rigid crack filler (such as Ardex Ardifix, CMP CM10 or equivalent) designed for use in control or saw-cut cuts. Follow material manufacturer's instructions for installation. Ensure surface is troweled flush with surface of concrete.


Consult a structural engineer prior to treating any crack or joint, especially those that may affect structural integrity (such as expansion joints). Review all manufacturer installation instructions and/or consult manufacturer technical staff for all crack or joint filling products prior to treating joints and cracks.

5. PRODUCT INSTALLATION


Ensure substrate is suitably prepared prior to installation, as manufacturer is not responsible for substrates that have not been properly prepared and tested for moisture. Ensure adhesive is approved for use with flooring material

Installation Patterns

MONOTHILIC



QUARTER-TURN



and that proper trowel type and size is used, as manufacturer is not responsible for any and all adhesion issues related to improper adhesive selection or usage.

Prior to installation, confirm material installation pattern and direction per

design specifications or work order. Inspect all tiles before installing or during installation to verify that there are no visible defects, damages or excessive shading variations. Do not blend materials from different cartons and avoid mixing cartons and pallets whenever possible. Some flooring products, colors and textures have latent and acceptable color and shade variations. If there are concerns regarding shade or color variation, do not install material and consult a sales representative and manufacturer's technical staff.

Ensure substrate is clean, dry, flat and sound prior to installation. Ensure the room is square using the 3-4-5 squaring rule or similar method to ensure acceptable installation. Dry-lay several pieces of material in order to determine ideal room layout.

Due to the hardness and durability of Versa Quartz, a tile cutter should be used for all standard cuts. For intricate or specialty cuts, use a tungsten-carbide blade and heat the back of the tile using a heat gun or equivalent to ease cutting. Pre-cut borders and other specialty pieces to fit snugly against or around walls, thresholds, transition strips, fixtures and other protrusions or accessories.

Use a nail-down guide or equivalent along starting row to expedite wet-set installation. Apply adhesive according to instructions for specific product in use and observe adhesive flash times, if applicable. Ensure all adhesive working

Adhesive Coverage Rates (Per Gallon)

| Adhesive | Porous | Non-Porous |
|----------|------------------------|----------------------------|
| SP-500 | 150 sq. ft. | |
| AP-520 | 320 sq. ft. | 400 sq. ft. |
| AW-510 | 160 sq. ft. | N/A |
| | Brushed & Rough Porous | Smooth Porous & Non-Porous |
| EW-710 | 135 sq. ft. | 150 sq. ft. |

times are observed and followed. Be sure to follow instructions based on substrate

porosity (porous or non-porous). Use below chart for reference.

Install material into adhesive and observe directional markings on back of tile to ensure markings are installed in the same direction **and** on the same side of the tile (see installation patterns above), even if installing in a specific and pre-determined design, such as a quarter-turn or herringbone design. Wipe the back and sides of tiles as necessary to remove dust. Use a pyramid layout when installing tiles to eliminate run-off. When installing into adhesive using a wet-set method, avoid walking or working on material until adhesive has cured for light foot traffic. Working on material that is installed into wet adhesive could cause adhesive to displace. When working off of material is not possible, use a kneeling board or equivalent to disperse weight evenly and prevent adhesive displacement. Pay close attention to working time to avoid adhesion issues. This may require installing material in smaller sections. Replace trowels at recommended intervals to maintain proper trowel ridge and spread rate.

Periodically lift material to ensure proper adhesive transfer and ensure adhesive has not surpassed the open time – adhesive should cover 90% of tile. Roll material with a 3 section, 100 lb. roller within 30 minutes of installation, crossing in a perpendicular direction after initial roll. Use a hand roller in areas that cannot be reached with larger roller.

Visually inspect installation to ensure that material has not shifted and that adhesive has not been squeezed out of joints or compressed onto surface. Clean excessive adhesive or adhesive residue from the surface of the material per adhesive recommendations. Do not apply abrasive or solvent based cleaners directly to flooring material.

6. FLOORING PROTECTION

Protect newly installed flooring with construction grade paper or protective

boards, such as Masonite or Ram Board, to prevent flooring damage, especially by other trades. Limit usage and foot traffic according to the adhesive's requirements. When moving appliances or heavy furniture, protect flooring from scuffing and tearing using temporary floor protection.

All furniture casters must be made of a soft material and must have a contact point of at least 1" in width to limit indentation and flooring damage. All rolling chairs or seating must have a resilient flooring chair pad installed over the finished floor to protect floor covering. All fixed furniture legs must have permanent felt or soft rubber floor protectors installed on all contact points and to reduce indentation. Floor protectors must have a flat contact point of at least 1 sq. in. or 1 in. diameter and must cover the entire bottom surface of the furniture leg.

Ensure all furniture castors and chair legs are clean and free of any and all dirt and debris. Routinely clean chair castors and furniture legs to ensure that dirt or debris has not built up or become embedded in castors or floor protectors. Replace chair castors and floor protectors at regular intervals, especially if they become damaged or heavily soiled.

Place walk-off mats at outside entrances. Ensure mats are manufactured with non-staining backs to prevent discoloration.

7. INITIAL MAINTENANCE

Ensure that adhesive has cured for recommended period of time prior to conducting initial maintenance. Remove any protective coverings prior to cleaning. Sweep, dust mop and/or vacuum flooring to remove any dirt, dust or debris.

Mix 2-4 ounces of Excelsior NC-900 Neutral Cleaner per gallon of clean, potable water. Use a clean mop to apply cleaning solution to floor and let stand for 5-10 minutes.

Using a low-speed floor buffer or swing single disc scrubber (180 – 360 RPM), buff floor while wet using a 3M 5300 Blue Cleaning Pad. If flooring is heavily

soiled, an additional cleaning may be required.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry entirely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing) and allow floor to dry entirely.

Do not use detergents, abrasive cleaners or “mop and shine” type products, as they will dull the finish and sheen of the flooring material. Do not use vacuums that have a beater bar or electric brooms

| Adhesive Traffic Limits | |
|-------------------------------|-------------|
| SP-500 Acrylic Aerosol | |
| Foot Traffic: | Immediate |
| Heavy / Rolling Traffic: | Immediate |
| Maintenance: | 48 Hours |
| AP-520 Acrylic Roll-On | |
| Foot Traffic: | Immediate |
| Heavy / Rolling Traffic: | Immediate |
| Maintenance: | 72 Hours |
| AW-510 Acrylic Wet Set | |
| Light Foot Traffic: | 24 Hours |
| Heavy / Rolling Traffic: | 48 Hours |
| Maintenance: | 72 Hours |
| EW-710 Epoxy Wet Set | |
| Foot Traffic: | 8-12 Hours |
| Heavy Foot/Rolling Traffic: | 24-48 Hours |
| Maintenance: | 48 Hours |

with hard plastic bottoms or no padding, as this may cause discoloration, scratching and loss of sheen.

Installation areas that will be difficult to maintain with a buffer or auto-scrubber, such as elevators cabs or small rooms, as well as areas that will not receive routine maintenance with a buffer or auto-scrubber must have a compatible floor finish installed, such as the Excelsior MF-940 or GF-950, in order to ease maintenance of the floor covering.

For further information regarding daily or routine maintenance, please consult the product care & maintenance document or the associated product technical data sheet.

8. FINISH APPLICATION

Prior to final usage, Versa Quartz must have a protective floor finish installed to ease maintenance and protect the floor covering. Ensure that initial maintenance has been conducted prior to applying floor finish. Flooring area must be free of dust, dirt, debris, adhesive or cleaning residues, mold release agents and any potential contaminants.

Apply a minimum of 2 coats of Excelsior MF-940 Acrylic Matte Floor Finish or GF-950 Acrylic Gloss Floor Finish. Allow each coat to dry completely before apply additional coats. Allow finish to cure for 12 hours prior to allowing foot traffic. If a better appearance is desired, 3-4 coats of finish can be applied.

For further information regarding finish application, please consult the product care & maintenance document or the associated product technical data sheet.

9. WARRANTY

Procedo provides a Fifteen Year Limited Commercial Warranty. For additional information, see associated warranty documents.

**V
E
R
S
A
Q
U
A
R
T
Z
T
I
L
E**

FOR PROFESSIONAL USE ONLY. PLEASE CONSULT ALL ASSOCIATED TECHNICAL DATA SHEETS, SAFETY DATA SHEETS, MAINTENANCE DOCUMENTS, WARRANTY INFORMATION PRIOR TO INSTALLATION.